

Incremento puertas voladas

BASES Y BASES GOLA	VUELO	1	2	3	4	5	6	7	8	9	10
	5	6	7	8	10	14	19	24	29	34	39
	10	9	10	11	13	17	22	27	32	37	42
	15	12	13	14	16	20	25	30	35	40	45
	20	15	16	17	19	23	28	33	38	43	48
	25	18	19	20	22	26	31	36	41	46	51
	30	22	23	24	26	30	35	40	45	50	55

COLGANTES	VUELO	1	2	3	4	5	6	7	8	9	10
	5	8	9	10	12	16	21	26	31	36	41
	10	11	12	13	15	19	24	29	34	39	44
	15	14	15	16	18	22	27	32	37	42	47
	20	17	18	19	21	25	30	35	40	45	50
	25	20	21	22	24	28	33	38	43	48	53
	30	24	25	26	28	32	37	42	47	52	57

COLUMNAS	VUELO	1	2	3	4	5	6	7	8	9	10
	5	12	13	14	16	22	29	37	42	47	52
	10	15	16	17	19	25	32	40	45	50	55
	15	18	19	20	22	28	35	43	48	53	58
	20	21	22	23	25	31	38	46	51	56	61
	25	24	25	26	28	34	41	49	54	59	64
	30	28	29	30	32	38	45	53	58	63	68